



ES ProSeal XL4 Inject for Home – Installation Instructions
Professional Use Only Instructions for Use:

Step 1:



Turn the a/c system on, and verify the unit is running. Connect ProSeal XL4 Inject to the low-side service port of the system.
(This is generally the large line.)

Step 2:



Connect the manifold refrigerant hose to the refrigerant supply tank. Verify the high and low side valves on the manifold are closed before proceeding. Purge the low pressure hose when connecting to the ProSeal XL4 Inject.

Step 3:

Open low side valve, watch for the tube to clear. (This will ONLY take a few seconds!) Turn off low side manifold valve as soon as the tube is clear.

Turn off refrigerant gas. Verify the system is charged to manufacturer's specifications.

Disconnect low side hose from ProSeal XL4 Inject. Install service port cap.

Run the a/c unit at least one hour after installing ProSeal XL4 Inject.

WARNING: Flammable liquid and vapor.



Do Not Mix with Ammonia! Always wear PPE (Personal Protective Equipment) when servicing HVAC equipment. Causes skin irritation and/or serious eye irritation. May cause respiratory irritation, drowsiness, and/or dizziness. Suspected of damaging the unborn child. May cause damage to organs through prolonged or repeated exposure.

PREVENTION: Do **NOT** handle or use this product until all safety precautions have been read and understood. **Keep away from heat/sparks/open flame/hot surfaces – NO SMOKING!** Keep container tightly closed. Make sure equipment is properly grounded. Use only explosion proof electrical/ventilation/lighting equipment. Use only non-sparking tools. Protect against static discharge – Take Precautionary measures. Wash thoroughly after handling. Use **ONLY** in a well-ventilated areas. Do **NOT** breathe mist or vapor! Wear protective gloves/protective clothing/eye and face protection.

FIRST AID MEASURES:

Inhalation: When symptoms occur: go into open air and ventilate suspected area. Immediately call a POISON CENTER or doctor/physician.

Skin Contact: Get immediate medical attention.

Eye Contact: Rinse cautiously with water for several minutes. Remove contact lenses, if present and easy to do. Continue rinsing. Immediately call a POISON CENTER or doctor/physician.

Ingestion: Do not induce vomiting. Immediately call a POISON CENTER or doctor/physician.

IN CASE OF FIRE: Use appropriate measures to extinguish fire.

STORAGE: Technical Measures: Comply with applicable regulations. Containers should be stored upright with valve protection cap in place and firmly secured to prevent falling. Keep Temperatures below 52°C/125°F. Store in a dry/cool/well-ventilated place. Keep in fireproof place. Store locked up. Incompatible products: Heat sources and Oxidizers.

DISPOSAL: Dispose of contents in accordance with all local/regional/national/international regulations.

WARNING: This product contains a chemical known to the State of California to cause birth defects or other reproductive harm.

Enviro-Safe Refrigerants, Inc.
400 Margaret / 400 Hanna Dr.
Pekin, IL 61554
1-888-913-1110 / 1-309-346-1110
<http://www.es-refrigerants.com>